


Mobile App User Manual

Content

1. Login to Your Mobile App	03
2. Asset Live Location and Update Information (Live Assets)	04
3. Asset Live Location and Update Information (Protect Assets)	05
4. Setting Alarm Notifications — Individual Assets (Live Assets)	06
5. Setting Alarm Notifications — Individual Assets (Protect / Loc8 Assets)	07
6. Setting Alarm Notifications — Multiple Assets	08
7. Completing a Playback (Only Live Assets)	09
8. Setting Geofence (Only Live Assets)	10
9. Create Report (Only Live Assets)	11
10. Adding Contacts To The Contact List	12
11. Recharging Credits	13
12. Upgrade To Live (Protect and Loc8 Assets)	14
13. Change Password	15
14. Viewing Recent Alarms (Only Live Assets)	16
15. Shared Assets	17
16. Purchase Fuel Report	18
17. Share Tracking Link	19


Login to Your Mobile App



Hint:

We strongly recommend you modify the default password for maximum account security.


Asset Live Location and Update Information (Live Assets)



Hint:


Need directions? Click on the GO TO option on the tracking page to access your mapping software.

Asset Live Location and Update Information (Protect Assets)




05

Setting Alarm Notifications — Individual Assets (Live Assets)



Setting Alarm Notifications — Individual Assets (Protect / Loc8 Assets)



Setting Alarm Notifications — Multiple Assets

All 10 Protect 10 Setting alarms for a fleet has never been easier: 9:40 1. Select the **Menu icon**: •-Alarms 2. Select the Alarms tab; • Protect (0) 3. Select the Category (Protect, Loc8, Live) and Assets you wish SELECT / UNSELECT ALL Geofence for the alarm to apply to; •- $\overline{\mathbf{v}}$ Jacob Nilsen 4. Select the **Tick** to move forward; • Shared Assets Volvo EC480 \sim 5. Select the **Applicable alarms**; • Contacts 6. Select the **Tick** to Save the alarms. • Alarms SELECT / UNSELECT ALL PUSH NOTIFI... Hint: Power Disconnect Remaining Enter Geofence Not receiving audible and visual alarm notifications? Check the bellow Leave Geofence settings: Intrusion Alert Alarms are selected and turned on Tilt / Shock Your settings permissions for the app are turned on – Low Battery this includes banners, storage and sound notifications Geolock Alert Ignition On Your mobile data is active. Ignition Off Want to see your alarm log? Select the BELL icon in the top right hand Positive Input corner to view all of the saved alarms. Please note if you "swipe" Negative Input the alarm off the notification screen it will not save. Harsh Braking **Fatigue Driving**

Harsh Accelerate

Completing a Playback (Only Live Assets) Home Protect 1 Loc8 0 The Playback will show you the assets route, speeds, stops Alex car and statistical information: Transperth Start Date and Time 12/02/2020, 10:00 1. **Select** the asset for which you want to view the Playback; • End Date and Time 14/02/2020.10:00 2. Select the Playback tab; • Alex car Ignition On, Stopped, Enter Geo... Trips Activity 3. Set the **Start** and **End date** and times; Show Optimized Click the **Apply icon**; 4. The recorded route will display on a Map. This will allow you to Toggle the desired time and and playback speed; • Alex car Transperth, Watkins Street, White Gum Valley Fremantle Western Australia Alex car Leach/Airport Exit, Cloverdale, Perth, 2020-01-09 11-2 09.01.2018 1:34 PI Western Australia, Australia Transperth, Wat Fremantle, West 2020-01-09 11:47:12 Slow 1h 31mir Stopped 20 Lilian Fowler Australia Transperth, Watkins Street, White Gum Valley, Fremantle, Western Australia 2020-01-09 08:1 20 Lilian Fowler Hint: Australia 25min 11 2020-01-09-07-4 In the tabs: Summary, Trips and Activity you can view more detailed 1/185 Sydenhan Australia information about trips and events.

The longer the playback the more time it may take to download the data. Access up to 30 days of playback data in one report on the

WEBSITE login.

2020-01-09 05 12 45

11min 56s

2020-01-09 05:01:12

1/185 Sydenham Road, Marrickville NSW 2204


Setting Geofence (Only Live Assets)

Geofences are a great way to log and receive notifications when an asset enters or leaves a designated area:

- 1. On the Menu screen, select **Geofence**; •
- 2. In the screen that appears, select the **Plus (create) icon**; •
- 3. The Geofence will display on a Map. Add the **Necessary** information and set the geofence **Radius**. •


Hint:

Want to quickly secure a GEOFENCE around your assets current position? Click the GEOLOCK option on the assets STATUS page.




Create Report (Only Live Assets)


Adding contacts to the contact list.




Adding Contacts To The Contact List




Recharging Credits




Upgrade To Live (Protect and Loc8 Assets)




Change Password



Viewing Recent Alarms (Only Live Assets)



Shared Assets



Purchase Fuel Report

Home If you would like to submit a fuel purchase report for reporting purposes, please follow the steps below. Search Volvo EC480 1. Select the **Asset name**; • 80 km/h 2. On the status screen, click on the petrol station icon; •-Transperth, Watkins Street, White 2022-01-21 12:23:11 3. Fill out the form, take a photo of the receipt Volvo EC480 Last update 2020-01-13 15:47:00 Geolock ?? and click on the **confirm icon** in the upper right corner. Lakes Rd & Minilva Pkwv, Greenfields WA 6210, Australia Purchase Fuel 49% 4+ 12.1 V 76% North (0°) REPORT THEFT 6 0 Q Petrol Station Amount Of Fuel Amount Of Fuel Type Of Fuel Type Of Fuel Price Notes 9

Share Tracking Link

